

**25B1 / B3**

Part No.	Code No.	Description	Q'ty
25B1	25B1	Motor (1/2 Hp, Single Ph)	
25B3	25B3	Motor (1/2 Hp, 3 Ph)	
BZZ-6202	BZZ-6202	Bearing (# 6202)	1
BZZ-6205	BZZ-6205	Bearing (# 6205)	1
25B	25B	Motor (1/2HP/Worm Shaft)	
25B-1	Q03-0303	Oil Seal	1
25B-2	C01-0343-1	Motor Cover Front	1
25B-3	H45-0331	Motor Shaft	1
25B-4	C01-0345	Motor Frame	1
25B-5	C01-0344-1	Motor Cover Back	1
25B-6	E01-0307	Fan	3
25B-7	S53-4150	Screw	1
25B-8	E01-0305	Fan Cover	3
25B-9	S53-0412	Screw	
46A	46A	Switch Box Kit	1
46A-1	U01-0303	Box Half	
46A-2	S53-0412	Screw	4
46A-3	U01-0302	Box Cover	1
46A-4	S94-3525	Screw	4
46A-5	J01-0303	Cord Socket	1

50A1 / A3

Part No.	Code No.	Description	Q'ty
50A1	50A1	Motor (1/4 Hp, Single Ph)	
50A3	50A3	Motor (1/4 Hp, 3 Ph)	
BZZ-6203	BZZ-6203	Bearing (# 6203)	1
BZZ-6206	BZZ-6206	Bearing (# 6206)	1
50A	50A	Motor Kit (1HP/Shaft)	
50A-1	C01-0347-1	Motor Cover Front	1
50A-2	H45-0322	Motor Shaft	1
50A-3	C01-0349	Motor Frame	1
50A-4	C01-0348-1	Motor Cover Back	1
50A-5	E01-0307	Fan	1
50A-6	S53-4150	Screw	4
50A-7	E01-0301	Fan Cover	1
50A-8	S53-0412	Screw	4
46A	46A	Switch Box Kit	
46A-1	U01-0303	Box Half	1
46A-2	S53-0412	Screw	4
46A-3	U01-0302	Box Cover	1
46A-4	S94-3525	Screw	4
46A-5	J01-0303	Cord Socket	1

45A1 / A3

Part No.	Code No.	Description	Q'ty
45A1	45A1	Motor (1 Hp, Single Ph)	
45A3	45A3	Motor (1 Hp, 3 Ph)	
BZZ-6203	BZZ-6203	Bearing (# 6203)	1
BZZ-6206	BZZ-6206	Bearing (# 6206)	1
45A	45A	Motor 1HP/Worm Shaft	
45A-1	Q03-0301	Oil Seal	1
45A-2	C01-0347-1	Motor Cover Front	1
45A-3	H45-0339	Motor Shaft	1
45A-4	C01-0349	Motor Frame	1
45A-5	C01-0348-1	Motor Cover Back	1
45A-6	E01-0307	Fan	1
45A-7	S53-4150	Screw	4
45A-8	E01-0301	Fan Cover	1
45A-9	S53-0412	Screw	4
46A	46A	Switch Box Kit	
46A-1	U01-0303	Box Half	1
46A-2	S53-0412	Screw	4
46A-3	U01-0302	Box Cover	1
46A-4	S94-3525	Screw	4
46A-5	J01-0303	Cord Socket	1

85B1 / B3

Part No.	Code No.	Description	Q'ty
85B1	85B1	Motor (1/4 Hp, Single Ph)	
85B3	85B3	Motor (1/4 3 Hp, 3 Ph)	
BZZ-6202	BZZ-6202	Bearing (# 6202)	1
BZZ-6205	BZZ-6205	Bearing (# 6205)	1
85B	85B	Motor (1/4HP/Worm Shaft)	
85B-1	Q03-0303	Oil Seal	1
85B-2	C01-0350-1	Motor Cover Front	1
85B-3	H45-0340	Motor Shaft	1
85B-4	C01-0352	Motor Frame	1
85B-5	C01-0351-1	Motor Cover Back	1
85B-6	E01-0308	Fan	1
85B-7	S53-4135	Screw	3
85B-8	E01-0303	Fan Cover	1
85B-9	S53-0412	Screw	3
86B	86B	Switch Box Kit	
86B-1	U01-0316	Box Half	1
86B-2	S53-0412	Screw	4
86B-3	U01-0315	Box Cover	1
86B-4	S94-3522	Screw	4
86B-5	J01-0305	Cord Socket	1