



#070403

ANA1550C0B
(ASN-1550)

97.04



#070403

ANA1550C0B
(ASN-1550)


NO	NEW PART NO	OLD PART NO	DESCRIPTION	QTY
2	BNABF06000	N0765AF196	Exhaust Cover	1
3	CMDO6220	M-D0622	Bolt M6x22	1
5	BNABA01000	N0765AA101	Body Cap	1
6	COA54350	O-55435	O-Ring	2
8	BNABA21000	N0765AA201	Valve Piston	1
9	COA37821C	O-37821	O-Ring	2
10	COA420400	O-42040	O-Ring	1
11	BNABA04000	N0765AA104	Valve Guide	1
13	CW0061310	M0365AA105	Washer	2
15	COA542190	O-54219	O-Ring	1
16	BNAB01000	N0765AB101	Main Cylinder	1
18	COP44	O-P44	O-Ring	1
19	BNABC02000	N0765AC102	Main Piston	1
20	CW0101610	M0759AC104	Washer	1
21	BNADC03000	M0750AC103	Hex Nut	1
22	BNAGC01000	N1550AC101	Driver Blade	1
23	BNAB02000	N0765AB102	Main Piston Stop	1
25	BNABF01000	N0765AF101	Body House	1
28	COA052190	O-05219	O-Ring	2
29	BNABF04000	N0765AF104	Air Pipe	1
30	BFAAF08000	F0350AE602	Washer	1
31	COA168200	O-16820	O-Ring	1
32	BFAAE21000	F0350AE201	Cabinet of Air Switch	1
33	COP4	O-03819	O-Ring	1
34	COA052190	O-05219	O-Ring	1
35	COP8	O-P8	O-Ring	1
36	BFAAE41800	F0350AE401	Pole	1
37	BFAAE61000	F0350AE601	Spring	1
38	COA025140	O-02514	O-Ring	2
39	BFAAE31000	F0350AE301	Stem of Air Switch	1
40	BFAAE01000	F0350AE101	Trigger Valve Housing	1
41	COA135140	O-13514	O-Ring	1
43	CPJ3024	P-S3024J	Spring Pin	3
44	BNAAW15000	M0365BW115	Guide of Actuate Arm	1
45	BNAAW16000	M0365BW116	Spring	1
46	BNAAD01000	M0365AD101	Main Trigger	1
50	CMV04259	N-V0425	Bolt MV4x25	2
51	CMDO5250	M-D0525	Bolt M5x25	4

NO	NEW PART NO	OLD PART NO	DESCRIPTION	QTY
52	CMR05350	M-R0535	Bolt M05x35	2
58	BMAAGP04000	M1550BP104	Staple Feeder	1
61	BMAAGP05000	M0365BP105	Spring	2
62	BMAAQ01000	M0365BQ101	Magazine, Left	1
63	BMAAW07000	M0365BW107	Magazine, Right	1
64	BMA3W11000	M1550BW111	Bolster	2
65	BMAAGW12000	M1550BW112	Bolster	1
66	BNAAW41000	M0365BP401	Magazine Lock	1
67	BMAAP44100	M0365BP404	Torsional Spring	1
68	CPP4028	P-P4028	Roller Pin	1
70A	BMAAR01000	M0365BR100	Magazine Cover	1
71	CPP4010	P-P4010	Roller Pin	1
72	CMDO5450	M-D0545	Bolt M5x45	1
73	CN1051	N-5	Hex Bolt	1
74	BNABWC8000	N0765BW108	Supporter	1
75	CMDO6120	M-D0612	Bolt M6x12	2
76	CMR03200	M-R0320	Bolt M03x20	1
77	BMAAQ03000	M0365BQ103	Spring	1
80	BMAAQ02000	M0365BQ102	Contact Arm Lock	1
81	CPJ2510	P-S2510J	Pin	1
82	BMAAQ04000	M0365BQ104	Lock Board	1
83	CN1031	N-3	Hex Bolt	1
84	BNABW31000	N0765BW201	Contact Arm	1
87	COA660260	O-66024	O-Ring	1
91	CN1061	N-6	Hex Nut	1
93	BNABA02000	N0765AA102	Spring	1
97	CPJ3016	P-S3016J	Spring Pin	1
98	BMAAD02000	M0365AD102	Secondary Trigger	1
99	CN1041	N-4	Bolt	2
102	BMAAGP02000	M1550AF102	Driver Guide	1
103	BMAAGW01000	M1550BW101	Main Bit Guide	1
104	CMLO5060	M-D0506	Bolt M5x6	1
105	BMAAGP22000	M1550BP202	Secondary Bit	1
113	CCS10	C-S10	C-Ring	1
114	BMAAGP21000	M1550BP201	Feeder Guide	1
200	BNAGC00000	N1550AC000	Driver Assembly	1
201	BFAAE00000	F0350AE000	Air Switch Unit	1

#D70402

AMA1550C0B
(ASM-1550)

97.04



#D70402

AMA1550C0B
(ASM-1550)

ITEM	NEW PART NO	OLD PART NO	DESCRIPTION	QTY
2	BMAAF06000	M0365AF106	Exhaust Cover	1
3	CMD06250	M-D0625	Bolt M6x25	4
4	CW0061108	W-6	Washer	8
5	BMAAA01000	M0365AA101	Body Cap	1
6	COA500330	O-50033	O-Ring	1
7	COA319200	O-31920	O-Ring	1
8	BMAAA21000	M0365AA201	Valve Piston	1
9	COA350200	O-35020	O-Ring	1
10	COA420400	O-42040	O-Ring	1
11	BMAAA04000	M0365AA104	Valve Guide	1
13	CW0061310	M0365AA105	Washer	1
15	COA470250	O-47025	O-Ring	2
16	BMAAB01000	M0365AB101	Main Cylinder	1
18	COP38	O-P38	O-Ring	1
23	BMAAB02000	M0365AB102	Main Piston Stop	1
25	BMAAF01000	M0365AF101	Body Housing	1
26	COP12	O-P12	O-Ring	2
27	BMAAE02000	M0365AE102	Valve Casing	1
28	COP3	O-P3	O-Ring	1
29	COP9	O-P9	O-Ring	3
30	BMAAE41000	M0365AE401	Valve Pole	1
32	BMAAE42000	M0365AE402	Spring	1
34	BMAAE51000	M0365AE501	Valve Body	1
35	COA092100	O-09210	O-Ring	1
36	BMAAE61000	M0365AE601	Spring	1
37	BMAAE31000	M0365AE301	Stem of Air Switch	1
38	COA025140	O-02514	O-Ring	2
39	BMAAE22000	M0365AE202	Air Switch Housing	1
40	COA052190	O-05219	O-Ring	1
43	CPJ3024	P-S3024J	Spring Pin	3
44	BMAAW15000	M0365BW115	Guide of Actuate Arm	1
45	BMAAW16000	M0365BW116	Spring	1
46	BMAAD01000	M0365AD101	Main Trigger	1
49	CMD06300	M-D0630	Bolt M6x30	4
50	CMV04259	M-V0425	Bolt MV4x25	2
51	CMD05250	M-D0525	Bolt M5x25	4
52	CMR05350	M-R0535	Bolt MD5x35	2
58	BMAAGP04000	M1550BP104	Staple Feeder	1
61	BMAAP05000	M0365BP105	Spring	2
62	BMAAQ01000	M0365BQ101	Magazine, Left	1

ITEM	NEW PART NO	OLD PART NO	DESCRIPTION	QTY
63	BMAAW07000	M0365BW107	Magazine, Right	1
64	BMAAGW11000	M1550BW111	Bolster, Side	2
65	BMAAGW12000	M1550BW112	Bolster, Middle	1
66	BMAAP41000	M0365BP401	Magazine Lock	1
67	BMAAP44000	M0365BP404	Torsional Spring	1
68	CFP4028	P-P4028	Roller Pin	1
70A	BMAAR01000	M0365BR100	Magazine Cover	1
71	CP24030	P-P4030	Roller Pin	1
72	CMD05450	M-D0545	Bolt M5x45	1
73	CN1051	N-5	Hex Bolt	1
74	BMAAW08000	M0365BW108	Supporter	1
75	CMD06120	M-D0612	Bolt MD6x12	2
76	CMR03200	M-R0320	Bolt MD3x20	1
77	BMAAQ03000	M0365BQ103	Spring	1
80	BMAAQ02000	M0365BQ102	Contact Arm Lock	1
81	CPJ2510	P-S2510J	Pin	1
82	BMAAQ04000	M0365BQ104	Lock Board	1
83	CN1031	N-3	Hex Bolt	1
84	BMAADW31000	M0750BW201	Contact Arm	1
87	COA492140	O-49214	O-Ring	2
91	CN1061	N-6	Bolt	1
92	BMAAF07000	M0365AF107	Washer	1
93	BMAAA02000	M0365AA102	Spring	3
94	CMD06400	M-D0640	Bolt M6x40	1
97	CPJ3016	P-S3016J	Spring Pin	1
98	BMAAD02000	M0365AD102	Secondary Trigger	1
99	CN1041	N-4	Bolt	2
100	BMAAF03000	M0365AF103	Driving Seat	1
102	BMAAGF02000	M1550AF102	Driver Guide	1
103	BMAAGW01000	M1550BW101	Main Bit Guide	1
105	BMAAGP22000	M1550BP202	Secondary Bit Guide	1
107	BMAAD02000	M0750AC102	Main Piston	1
108	CW0101610	M0750AC104	Washer	2
109	BMAAD03000	M0750AC103	Bolt	1
110	BMAAGC01000	M1550AC101	Driver Blade	1
113	COS10	C-S10	C-Ring	1
114	BMAAGP21000	M1550BP201	Feeder Guide	1
200	BMAAGC00000	M1550AC000	Driver Assembly	1
201	BMAAE00000	M0365AE000	Air Switch Assembly	1